

B Series Intrusion Kits

B5512 48-point Control Panel



Part Number	B5512	B11 (small)	B10 (medium)	B430 (PSTN)	B440 (cellular)	B441 (cellular)	B915	B920	B930	CX4010	ICP-TR1822-CAN
B5512-C	■		■							■	
B5512-C-CN	■		■								■
B5512-C-920	■		■					■		■	
B5512-C-930	■		■						■	■	
B5512-CC	■		■		■					■	
B5512-CC-920	■		■		■			■		■	
B5512-CC-930	■		■		■				■	■	
B5512-CC1	■		■			■				■	
B5512-CC1-920	■		■			■		■		■	
B5512-CC1-930	■		■			■			■	■	
B5512-CP	■		■	■						■	
B5512-CP-920	■		■	■				■		■	
B5512-CP-930	■		■	■					■	■	
B5512-D	■	■								■	
B5512-D-920	■	■						■		■	
B5512-D-930	■	■							■	■	
B5512-DC	■	■			■					■	
B5512-DC-920	■	■			■			■		■	
B5512-DC-930	■	■			■				■	■	
B5512-DC1	■	■				■				■	
B5512-DC1-920	■	■				■		■		■	
B5512-DC1-930	■	■				■			■	■	
B5512-DP	■	■		■						■	
B5512-DP-920	■	■		■				■		■	
B5512-DP-930	■	■		■					■	■	

	B5512E	B11 (small)	B10 (medium)	B430 (PSTN)	B440 (cellular)	B441 (cellular)	B915	B920	B930	CX4010	ICP-TR1822-CAN
B5512E-DC1	■	■				■				■	
B5512E-DC1-915	■	■				■	■			■	
B5512E-DP	■	■		■						■	
B5512E-DP-915	■	■		■			■			■	

B Series Intrusion Kits

B4512 28-point Control Panel



Part Number	B4512	B11 (small)	B10 (medium)	B430 (PSTN)	B440 (cellular)	B441 (cellular)	B915	B920	B930	CX4010	ICP-TR1822-CAN
B4512-C	■		■							■	
B4512-C-920	■		■					■		■	
B4512-C-930	■		■						■	■	
B4512-CC	■		■		■					■	
B4512-CC-920	■		■		■			■		■	
B4512-CC-930	■		■		■				■	■	
B4512-CC1	■		■							■	
B4512-CC1-920	■		■							■	
B4512-CC1-930	■		■							■	
B4512-CP	■		■	■						■	
B4512-CP-920	■		■	■				■		■	
B4512-CP-930	■		■	■					■	■	
B4512-D	■	■								■	
B4512-D-CN	■	■									■
B4512-D-920	■	■						■		■	
B4512-D-930	■	■							■	■	
B4512-DC	■	■			■					■	
B4512-DC-920	■	■			■			■		■	
B4512-DC-930	■	■			■				■	■	
B4512-DC1	■	■				■				■	
B4512-DC1-920	■	■				■		■		■	
B4512-DC1-930	■	■				■			■	■	
B4512-DP	■	■		■						■	
B4512-DP-920	■	■		■				■		■	
B4512-DP-930	■	■		■					■	■	

	B4512E	B11 (small)	B10 (medium)	B430 (PSTN)	B440 (cellular)	B441 (cellular)	B915	B920	B930	CX4010	ICP-TR1822-CAN
B4512E-DC1	■	■				■				■	
B4512E-DC1-915	■	■				■	■			■	
B4512E-DP	■	■		■						■	
B4512E-DP-915	■	■		■			■			■	

B Series Intrusion Kits

B3512 16-point Control Panel



Part Number	B3512	B11 (small)	B10 (medium)	B430 (PSTN)	B440 (cellular)	B441 (cellular)	B915	B920	B930	CX4010	ICP-TR1822-CAN
B3512-DC1	■	■				■				■	
B3512-DC1-920	■	■				■		■		■	
B3512-DP	■	■		■						■	
B3512-DP-CN	■	■		■							■
B3512-DP-920	■	■		■				■		■	
B3512-DP-920-CN	■	■		■				■		■	■

Part Number	B3512E	B11 (small)	B10 (medium)	B430 (PSTN)	B440 (cellular)	B441 (cellular)	B915	B920	B930	CX4010	ICP-TR1822-CAN
B3512E-DC1	■	■				■				■	
B3512E-DC1-915	■	■				■	■			■	
B3512E-DP	■	■		■						■	
B3512E-DP-915	■	■		■			■			■	