

Explosion Proof T5HO Fluorescent Ballast Instruction Manual

Do not attempt installation until you are familiar with all warnings, precautions, and procedures outlined within this instruction sheet. Read carefully before operating. Retain these instructions for future reference.

IMPORTANT

READ CAREFULLY BEFORE OPERATING THIS FIXTURE. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE. IF UNSURE ABOUT ANY PART OF THESE INSTRUCTIONS, CONSULT A QUALIFIED ELECTRICAL PROFESSIONAL.

WARNING: OPERATE ONLY AT THE VOLTAGE LISTED ON THE PRODUCT. DO NOT MAINTAIN IN CLOSE PROXIMITY OF COMBUSTIBLE OR FLAMMABLE MATERIALS. NEVER LOOK DIRECTLY AT LIGHT WHEN ON.

WARNING: CONSULT A QUALIFIED ELECTRICAL PROFESSIONAL/ELECTRICIAN TO INSTALL THIS DEVICE IN ACCORDANCE WITH APPROPRIATE LOCAL AND NEC CODES AND REGULATIONS.

WARNING: TO BE INSTALLED AND/OR USED IN ACCORDANCE WITH APPROPRIATE ELECTRICAL CODES AND REGULATIONS.

INSTALLATION


WARNING To reduce fire and shock hazard: Disconnect power before servicing; install and maintain to meet applicable codes; ensure fixture and wiring are properly grounded.

Replacement Guide

- Remove bolts around the box cover
- Remove cover
- Disconnect existing wires
- Unbolt and remove existing ballast
- Place and blot in new ballast
- Reconnect the wires
- Reinstall cover
 - See diagram below




WIRING DIAGRAM



FOR 1 LAMP OPERATIONS, CAP YELLOW LEADS

HOT SPOT LOCATION



Actual tc point is noted on each ballast label.