

T5HO Fluorescent Light Bulbs 4ft Tube Lights – Case of 12 Instruction Guide

Replacement 4 Foot Fluorescent Bulb. Ideal for spare or replacement bulbs on 4 foot fluorescent Larson Electronics fixtures as well as our Explosion Proof, 4 Foot, 4 Lamp Fixtures. Lamp options include F48-T12/HO – 60 watt, F32-T8/841 – 32 watt, F54-T5/841/HO – 54 watt, and F54-T5/850/HO – 54 watt. Selected lamp option is supplied.

Fluorescent lamps are not voltage specific, meaning there are no low voltage or high voltage fluorescent lamps. The fixture's battery/ballast system converts the incoming voltage to the voltage that the lamps require. This applies only to fluorescent lamps and NOT LED tube style replacement lamps.

WARNING

UNPLUG LAMP BEFORE SERVICING. EXISTING LAMPS MAY BE HOT. ALLOW TO COOL BEFORE SERVICING FIXTURE.

INSTALLATION

Replacement of the fluorescent bulbs is as follows:

- 1. Turn off power. Make sure power is turned off at the fuse box.
- 2. Allow fixture to cool before performing maintenance.
- 3. Remove old lamp. Follow instructions included with light fixture for replacing lamp and opening fixture.
- 4. Replace with new lamp. Insert new lamp into socket. Turn lamp until it locks into socket on both ends.
- 5. Replace the lens/cover of light fixture.
- 6. Restore power and switch on the light.

NOTICE:

Safety is crucial when working with electrical or wiring faults.

Remember:

Check the wattage on the used bulb and replace it with a bulb of the same wattage Dispose of the bulb well out of the reach of children Don't put your fingers in the exposed light socket

These instructions may not cover all details or variations of this product for your equipment or installation requirements. Should further information not covered by these instructions be required, please contact Larson Electronics by email at <u>sales@larsonelectronics.com</u> or by phone at 1-800-369-6671 for further assistance.

Please visit LarsonElectronics.com for Warranty and Return information.