

Adjustable Aluminum Rail Mount Bracket Scaffold / Ladder Rack Bracket - 1.9" OD Top Mounting Stud Instruction Manual

The aluminum rail/ladder bracket can be adjusted from 26 inches to 43 inches to allow mounting to a wide variety of railings, scaffolding or ladders, and includes a 1.9" OD stud for mounting lights or accessories.

WARNING

To avoid the risk of fire or electric shock, light heads should be installed, inspected and maintained by a qualified electrician only, in accordance with all applicable electrical codes.


MOUNTING

In order to mount the light head to the aluminum rail/ladder mount follow the steps below:

1. Make sure the hand screw is loose.
2. Install light head (not included) over top of mount and tighten hand screw.

To mount aluminum mount:

1. Securely mount the frame to any rail, ladder or scaffolding capable of holding the weight using the J-hooks.
2. The bottom J-hook can be loosened with the hand screw toward the base.
3. Loosen the lower hand screw and slide the bottom J-hook down.
4. Attach the top two J-hooks to the rail first, then push the bottom toward the next available rail.
5. Slide the bottom J-hook up until hooked and tighten hand screw.
6. The J-bracket can adjust 26 inches to 43 inches for various size mounting locations.



TO ADJUST LIGHT HEAD AFTER MOUNTING

The center mount pole is adjustable and can be elevated to three feet above the mounting bracket, helping to improve coverage and reduce glare. Loosen the upper hand screw and slide the light head vertically. Do not over extend! Allow at least 2 feet of pole within frame.

MAINTENANCE

Caution: To avoid personal injury, disconnect power to the light and allow the unit to cool down before performing maintenance.

Warning: No user serviceable parts inside of fixture. Risk of electric shock. Removal of the lens will void the warranty.

1. Perform visual, mechanical and electrical inspections on a regular basis.
2. Do not operate if and part of the mount is cracked or damaged.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT SALES@LARSONELECTRONICS.COM OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR **WARRANTY** AND **RETURN** INFORMATION.