

24V Replacement Incandescent Bulb Instruction Manual

Do not attempt installation until you are familiar with all warnings and procedures outlined within this instruction sheet.

WARNING:

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

CRITICAL SAFETY INSTRUCTIONS:

To avoid the risk of fire, explosion or electric shock, this product should be installed, inspected and maintained by a qualified electrician only, in accordance with all applicable electrical codes.

BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING MAINTENANCE.

INSTALLATION


WARNING: *Turn off power supply. Allow the fixture/bulb to cool.*

Low voltage light bulbs fit a variety of special applications, from RV and marine lighting to temporary battery-powered and low voltage lighting installations. The SB-24V is a 24 volt, A19 standard shape bulb that will fit most typical low voltage applications.

Open fixture following manufacture instructions. If fixture is in explosion proof area, **DO NOT** open within the hazardous area. Always remove from hazardous area before performing maintenance.

Remove old bulb by turning counter-clockwise until free from socket. Replace with new bulb and turn clockwise until snug.

WARNING: *Only to be used in 24V applications! DO NOT plug into any other voltage. Damage from improper voltage may void warranty.*



USE AND CARE

Perform visual, mechanical and electrical inspections on a regular basis. Always allow fixture to cool before performing maintenance.

Should further information not covered by these instructions be required, please contact Larson Electronics at 1-800-369-6671 or sales@larsonelectronics.com for further assistance.

WARRANTY

Please visit LarsonElectronics.com for **Warranty** and **Return** information.