

EXP-MS-N4X-AT-LV Explosion Proof Motion Sensor

Instruction Manual

Thank you for your purchase of the EXP-MS-N4X-AT-LV Motion Sensor, the following instructions are intended for this part number only.



Installation

This unit is easily wall mounted via integral mounting bracket, which can be adjusted -90° to +30° vertically after installation. The explosion proof housing provides two 1/2" or 3/4" hub openings located on either side of the housing for running electrical conductors in a feed through configuration. A bushing seal at each conductor opening prevents damage to wiring insulation.

This unit is designed to operate on low voltage 12-24V AC or DC electrical circuits. This motion sensor is suitable for use in environments where combustible dusts and particulates may be present. 1/2" or 3/4" NPT tapped conduit openings are provided on either of the unit in feed through versions while dead end versions have a single conduit hub, providing easy and secure connection to main power line supplies.

The EXP-MS-N4X-AT-LV operates like a standard on/off light switch. The circuit is normally open when no motion is present. Once motion is detected, the internal switch changes to a closed circuit, allowing voltage to pass through the sensor and power the device(s) at the other end.

The sensor is an active motion detector; it emits high-frequency electro-magnetic waves (5.8GHz) and receives their echo. The sensor detects the change in echo from even the slightest movement in its detection zone. A microprocessor then triggers the "switch light ON" command. Detection is possible through doors, panes of glass or thin walls.

IMPORTANT: persons or objects moving towards the sensor are detected best.

NOTE: the high frequency of the output of this sensor is <10Mw – that is just one 100th of the transmission power of a mobile phone or the output of a microwave oven.



Antenna module Daylight sensor	MOTION SENSOR		
	Operating voltage	12 or 24V AC/DC	
Daylight threshold	Power consumption Detection zone	5.8GHz±75MHz, ISM wave band <0.5mW ≤0.5W(standby) Max.(D x H): 16m x 15m	
<u>e</u>	Detection sensitivity	25% / 50% / 75% / 100%	
	Hold time	5s / 30s / 90s / 3min / 20min / 30min	
87.00	Daylight sensor	5Lux/15Lux/30Lux/50Lux/100Lux/Disable	
	Mounting height	15m Max.	
	Motion detection	0.5~3m/s	
	Detection angle	150°(wall installation)	
		360°(ceiling installation)	
	Operating temperature	-20℃~60℃	
	IP rating	IP20	

Setting

By selecting the combination on the DIP switch, sensor data can be precisely set for each specific application.


		1	2	
ON	Ι	ON	ON	100%
1	II	-	ON	75%
Í	III	ON	-	50%
	IV	-	-	25%

Detection area

Detection area can be reduced by selecting the combination on the DIP switches to fit precisely each application.

		3	4	5	
	Ι	ON	ON	ON	5s
ON ✿	II	-	ON	ON	30s
	III	ON	-	ON	90s
	IV	-	-	ON	3min
	V	ON	ON	-	20min
	IV	-	-	-	30min

		6	7	8	
ON	Ι	ON	ON	ON	5lux
1	II	-	ON	ON	15lux
	III	ON	-	ON	30lux
	IV	-	-	ON	50lux
	V	ON	ON	_	100lux
	VI	-	-	-	Disable



Hold time

Refers to the time period the lamp remains at 100% illumination after no motion detected.

Daylight sensor

The sensor can be set to only allow the lamp to illuminate below a defined ambient brightness threshold.

When set to Disable mode, the daylight sensor will switch on the lamp when motion is detected regardless of ambient light level. 30lux, 50lux, 100lux,:twilight operation, 5lux, 15lux: darkness operation only.

Mode

When set to Disable, the microwave sensor function is inactive, lights turns on or off by switch.

When set to Sensor, the microwave sensor function is active.



Certifications - Compliance

- Class I, Divisions 1 & 2, Groups B, C, D
- Class I, Zones 1 & 2, Groups IIB+H2, IIA
- Class II, Divisions 1&2, Groups E,F,G
- Class III, Divisions 1&2
- Ex db IIC Gb
- Ex tb IIC Gb Db IP66
- NEMA 3,4,4X,7 (B,C,D), 9 (E,F,G)

Malfunction	Cause	Remedy
The load will not work	- wrong light control setting selected	- adjust setting
	- load faulty	- change load
	- mains switch OFF	- switch ON
The load is always working	- continuous movement in the	- check zone setting
	detection zone	
Load works without and identifiable	- sensor is not mounted for detecting	- securely mount enclosure
movement	movement reliably	- check zone setting
	- movement occurred, but not	
	identified by the sensor (movement	
	behind a wall, movement of small	
	object in immediate vicinity etc.)	
The load will not work despite	-rapid movements are being	-check zone setting
movement	suppressed to minimize	
	malfunctioning or the detection zone	
	you have set is too small	

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT <u>SALES@LARSONELECTRONICS.COM</u> OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT LARSONELECTRONICS.COM FOR WARRANTY AND RETURN INFORMATION.