



SERIES HLSW CONTROL STATIONS

Control Stations For Use In Zone Classified Hazardous Locations

1. General Safety Information:

CAUTION:

Before installing, make sure you are compliant with area classifications, failure to do so may result in bodily injury, death and property damage. Do not attempt installation until you are familiar with the following procedures. All installation must comply with the applicable Electrical Code.

Make sure that the circuit is De-energized before starting installation or maintenance.

Verify that the installation is grounded. Failure to ground will create electrical shock hazards, which can cause serious injury and or death.

IMPORTANT:

Please read these instructions carefully before installing or maintaining this equipment. Good electrical practices should be followed at all times and this data should be used as a guide only

Technical information, advice and recommendations contained in these documents is based upon information that Larson Electronics believes to be reliable. All the information and advice contained in these documents is intended for use only by persons having been trained and possessing the requisite skill and know-how and to be used by such persons only at their own discretion and risk. The nature of these instructions is informative only and does not cover all of the details, variations or combinations in which this equipment may be used, its storage, delivery, installation, check out, safe operation and maintenance.

Since conditions of use of the product are outside of the care, custody and control of Larson Electronics, the purchaser should determine the suitability of the product for his intended use, and assumes all risk and liability whatsoever in connection therewith.

E X P E D I T E D S H I P P I N G · S U P E R I O R C U S T O M F A B R I C A T I O N

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143

p: 1-800-369-6671 • Int'l: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com

2. Installation Instructions



a: Using a screwdriver with a #2 Phillips Head, a Standard Slotted or Robertson style head, unscrew the retained cover screws. Install the back box of the control station securely on a flat surface using mounting screws that shall fit the hole or slot (see dimensional drawing) and shall not damage supplied hole or slot. The use of a washer is allowed. Mounting dimensions are shown on this document. Also for convenience the non-metallic enclosures have this information molded into the back surface.

The non-metallic enclosures are identified with "TOP" molded on the inside of the cover and the back of the box. The stainless steel enclosures have the slots located at the bottom.

b: Install the conduit or cable to the box using fittings that are Certified as suitable for the area classification and service environment.

c: Connect conductors to the component terminals. Follow all wire stripping and terminal torque instructions for each component as described below.

Grounding connections are available at the din rail, earth continuity plate and internal external ground stud, if supplied* and hub locknut.

Bonding connections are available on covers and boxes of all stainless steel enclosures. All exposed metal should be bonded per applicable local electrical codes.

* An Internal - External ground stud with securement hardware is supplied on all stainless steel enclosures, and is offered as an option for installing into non-metallic (polymeric) enclosures.

d: Perform a continuity check to ensure the circuit is wired properly for the intended use.

e: Replace the enclosure cover making note of "TOP" molded inside the non-metallic covers and the orientation of the actuators for the stainless steel enclosures. Thread each cover screw half way into the threaded insert without completely tightening in a diagonal pattern. Then complete installation of cover by tightening screws in the same diagonal pattern to a minimum torque of 2.9 Nm (26 lb-in) to a maximum of 3.4 Nm (30 lb-ins.).

Before replacing cover, ensure all wires are neatly installed within the control station base and are well away from the lid base joint and gasketing area.

DO NOT OVERTIGHTEN OR USE AN IMPACT TOOL.

A consistent fit over the entire length of the cover joint should be verified at the time of installation.

f: Turn ON the supply circuit and test the system.

WARNING: Electrical shock or personal injury can result from device misalignment. Be sure actuators align with each control module.

EXPEDITED SHIPPING • SUPERIOR CUSTOM FABRICATION

LARSON ELECTRONICS LLC • 9419 E US HWY 175 • KEMP, TX 75143

p: 1-800-369-6671 • inti: 903-498-3363 • f: 903-498-3364 • sales@larsonelectronics.com