

## Electromagnetic Ballast for 2G11 Base Fluorescent Fixture Instruction Manual

Thank you for your purchase of the Larson Electronics XLE-RBALL-2G11-60W-2X-120V 2G11 Electromagnetic Ballast.

### **WARNING:**

**READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.  
CRITICAL SAFETY INSTRUCTIONS:**

- INSTALLATION SHOULD ONLY BE CONDUCTED BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH NEC AND ANY RELEVANT LOCAL BUILDING CODES.
- RISK OF FIRE OR ELECTRIC SHOCK. FIXTURE INSTALLATION REQUIRES KNOWLEDGE OF LUMINAIRES ELECTRICAL SYSTEMS. IF NOT QUALIFIED, CONTACT A QUALIFIED ELECTRICIAN.
- BE CERTAIN ELECTRICAL POWER IS OFF BEFORE AND DURING INSTALLATION AND MAINTENANCE.
- MAKE SURE THE SUPPLY VOLTAGE IS THE SAME AS THE RATED LUMINAIRE FIXTURES VOLTAGE.
- TO PREVENT WIRING DAMAGE OR ABRASION, DO NOT EXPOSE WIRING TO EDGES OF SHEET METAL OR SHARP OBJECTS. SUITABLE FOR DAMP LOCATIONS.

---

The XLE-RBALL-2G11-60W-2X-120V from Larson Electronics is a Ballast for 2G11 base fluorescent fixtures.

### **Installation**

The XLE-RBALL-2G11-60W-2X-120V is designed for surface mounting via mounting tabs on the base of the ballast. Exact mounting specifics are left to the user. Mount the ballast to the desired surface, and complete wiring connections with supply wiring outputting the correct voltage for the socket. Be sure power is off at the breaker before completing the wiring connections. This ballast is rated for voltage of 120V AC and wattage of 130W. 2G11 fluorescent tubes are compatible bulbs for this ballast. Be sure the bulb and socket ratings match that of the ballast. Follow all local and national electrical codes when installing this ballast.

### **USE AND CARE**

Unauthorized modification may impair the function and/or safety of this device and could affect the life of the equipment. Always check for damaged or worn out parts before using the device. Store it in a secure place out of the reach of children when not in use. Inspect for good working condition prior to storage and before re-use.

### **REPLACEMENT PARTS**

The XLE-RBALL-2G11-60W-2X-120V is designed to provide years of reliable performance. Should the need for replacement parts arise, please contact Larson Electronics.

THESE INSTRUCTIONS MAY NOT COVER ALL DETAILS OR VARIATIONS OF THIS PRODUCT FOR YOUR EQUIPMENT OR INSTALLATION REQUIREMENTS. SHOULD FURTHER INFORMATION NOT COVERED BY THESE INSTRUCTIONS BE REQUIRED, PLEASE CONTACT LARSON ELECTRONICS BY EMAIL AT [SALES@LARSONELECTRONICS.COM](mailto:SALES@LARSONELECTRONICS.COM) OR BY PHONE AT 1-800-369-6671 FOR FURTHER ASSISTANCE.

PLEASE VISIT [LARSONELECTRONICS.COM](http://LARSONELECTRONICS.COM) FOR **WARRANTY** AND **RETURN** INFORMATION.